LOOP LOCK STOPPER REPLACEMENT INSTRUCTIONS





1. HAVE UMBRELLA CLOSED, THEN CRANK A LITTLE, PULL OUT THE TILT LEVER, THEN PUSH THE TILT LEVER TO THE SIDE.



2. REMOVE SCREW AND TAKE OUT THE LOOP LOCK STOPPER. USE HEX WRENCH (SHOWN BELOW). UNTIE THE KNOT AND DISCARD THE OLD STOPPER.



3. REPLACE NEW LOOP LOCK STOPPER. PUT THE CORD THROUGH THE NEW LOOP LOCK STOPPER ON THE FRONT SIDE.











4. THEN, PUT THE CORD THROUGH THE BOTTOM HOLE ON THE LOOP LOCK STOPPER.



5. MAKE A KNOT AS SHOWN IN PICTURE.





6. PUT THE TIED KNOT INSIDE THE TRACK WHERE THE LOOP LOCK STOPPER IS TO BE INSTALLED.



7. INSERT THE LOOP LOCK STOPPER INTO THE TRACK.



8. INSERT THE SCREW INSIDE THE HOLE.





(USE HEX WRENCH TO TIGHTEN THE BOLT)



9. PLACE THE TILT LEVER BACK INTO PROPER POSITION.